Information Data Sheet



Detector Tube Acetone-100

Part No. (US): 804141

Part No. D5086829

1. Application

Detection of acetone (propanone, C₃H₆O) in air or in technical gases.

2. Detector Tube Sampling Pump

KWIK DRAW(formerly MSA AUER) Gas-Tester[®] IIH, Gas-Tester[®] I / ThumbPump™-Sampler, Toximeter® II, Uniphos Kwik-Draw™-Pump or other suitable detector tubes pumps. Observe respective instructions for use.

3. Measuring Range

100 ... 10,000 ppm acetone at n=6 (6 strokes).

4. Chemical Reaction and Color Change

Reaction of acetone with 2.4-dinitrophenylhydrazine forming an hydrazone.

Color change: Light yellow Yellow



5. Ambient Conditions During Sampling

• Detector tubes can be used without compensation of the reading between 0 °C and 40 °C (32 °F and 104 °F) and up to 90% RH [46 g/m³ at 40 °C (104 °F)].

6. Interferences and Cross Sensitivities

- No interference from:
 - alcohols and esters.
- Aldehydes and other ketones will be indicated. The sensitivity of indication is different. Ammonia interferes with the reading by a yellow-brown discoloration of the indication layer.

Manufactured By: Uniphos Envirotronic Pvt. Ltd (100%EOU)

P.O. Nahuli - 396 108 Tal. Umbergaon,

Dist: Valsad, Gujarat, India Tel.: +91(260) 2730156 / 57 / 58 Fax: +91(260) 2730160

Marketing Office: Uniphos Envirotronic Pvt. Ltd Readymoney Terrace, 167, Dr. Annie Besant Road, Worli, Mumbai 400 018, India.

Tel.: +91(22) 6123 3500 Fax: +91(22) 2493 8826 +91 (22) 2497 8119

www.kwikdrawtubes.com