

Uniphos Detector Tube Data Sheet

Direct Reading Length of Stain Type

Carbon Monoxide co

SCO- 3

TWA (TLV): 25 ppm

STEL (TLV): 50 ppm

Flammable Range: 13-74%

Specification:

Measurement Range	Extended	Standard	Extended
	Do not extend	5-100 ppm	Do not extend
No. of Pump Strokes		3 (300 mL)	
Volume Correction Factor (VCF)*		1.0	
Sampling Time	3 minutes per pump stroke (100 mL)		
Color Change	White → Brownish green		
Shelf Life	1 year		
Storage condition	Below 10°C (50°F)		
Calibration condition	Calibrated at 20°C (68°F) and 50% RH.		
Reaction Principle	$\text{CO} + \text{I}_2\text{O}_5 + \text{H}_2\text{SO}_7 \rightarrow \text{I}_2$		
Relative standard deviation	± 10 %		

* Multiply the observed reading by the correction factor (VCF) to obtain the true concentration.

Possible Interferences:

Compound	Concentration (ppm)	Interference	Colour change / Comments
H ₂ S	100	No	No Effect
NH ₃	120	No	No Effect
Hydrogen	99.9 %	No	No Effect

Correction for Environmental Parameters:

Temperature	Not necessary between 0 - 40°C (32 - 104°F).
Relative humidity	Not necessary between 10 - 90 %.

Manufactured By: Uniphos Envirotronic Pvt. Ltd.
Nahuli (PO), Umbergaon (Tal.)
Valsad (Dist), Gujarat, India – 396108



Rev.0512